

STANDARD DEPARTURE
ROUTES – INSTRUMENT
(SID)

HERINGSDORF
RWY 10/28

Designator	Route	After Take-Off		Remarks
		Climb to	Contact	
1	2	3	4	5
RWY 10				
MASOR 1A	MASOR ONE ALPHA On track 103° via HC NDB to 5.0 DME IHEW; RT to intercept R087 FLD; on R087 FLD to 21.0 DME FLD; RT, on track 296° to MASOR (△).	5000 ft	Bremen Radar 134.650	After passing 21.0 DME FLD BRNAV equipment necessary.
PENET 2A	PENET TWO ALPHA On track 103° via HC NDB to 5.0 DME IHEW; RT to intercept R087 FLD; on R087 FLD to 21.0 DME FLD; RT, on R143 TRT to PENET (△).			
RWY 28				
MASOR 1B	MASOR ONE BRAVO On track 283° HC NDB to 10.2 DME IHEW; LT, on track 267° to MASOR (△).	5000 ft	Bremen Radar 134.650	After passing 10.2 DME IHEW BRNAV equipment necessary.
PENET 2B	PENET TWO BRAVO On track 283° HC NDB to 7.0 DME IHEW; RT, on R143 TRT to PENET (△).			